

## Moorestown Privacy/Locking Cremone Bolt

*Includes Moorestown Suited Trim*

BOL135-84 Moorestown Privacy Cremone Bolt for 7'0 Door

BOL135-96 Moorestown Privacy Cremone Bolt for 8'0 Door

BOL135-120 Moorestown Privacy Cremone Bolt for 10'0 Door

## Moorestown Dummy Privacy Cremone Bolt

*Includes Moorestown Suited Trim*

BOL147-84 Moorestown Dummy Privacy Cremone for 7'0 Door

BOL147-96 Moorestown Dummy Privacy Cremone for 8'0 Door

BOL147-120 Dummy Privacy Cremone for 10'0 Door

### Supplied Standard



2100-US  
Universal Strike



9941-045  
Double Sided  
Special Spindle



9150  
Rim Cylinder

### Optional Accessories



2100-AS  
Angle Strike



ACC171  
Moorestown Box Strike

## Cremone Bolt Accessories

2100-AS Optional Angle Strike

ACC171 Moorestown Box Strike

9150 Rim Cylinder

9931-020 Single Sided 2.0" Spindle

9941-045 Double Sided 4.5" Spindle

2700-06A Double Sided 6.0" Spindle for Thick Doors 3" Max Thickness

## Moorestown Locking Privacy Cremone Bolt

### Features:

Von Morris Moorestown Cremone Bolts feature a solid brass case CNC milled from brass billet and guides with an internal mechanism of brass and stainless steel. The Locking Cremone case is very narrow, less than 1.5", for use on narrow stiles of French doors and windows. Cremone Bolt locks from the exterior with a rim cylinder and inside with a turnpiece. Cremone case contains a cassette mechanism that can be handed simply by reversing the cassette. The Cremone can also be easily changed from lever operation (90° rotation) to knob operation (180°) simply by relocating the spindle. Shoot Bolts are attached to the Cremone mechanism with machine screws. Cremone Bolt design is very clean, featuring concealed Shoot Bolt guides. **Price Includes Moorestown Turnpiece and Cylinder Collar along with either a pair of Small Moorestown Levers or Knobs, and a small Moorestown Rose for the exterior**

### Guides::

End Guides have a flat spring operating on the front of the bolt to prevent rattling. The length of the Guide and placement of the spring conceals any scratches on the bolt caused by the spring. This End Guide design allows the bolts to be installed on the door and then cut to length at the job site.

### Locking Cremone Case Size:

Length of Cassette:	10.5"
Width:	1.5"
Height to edge of case:	0.787"
Height to face of knob/lever boss:	1.024"
Spindle hub to turnpiece spacing:	2.250"
Spindle hub to cylinder spacing:	2.467"

**Spindle Height:** Standard Spindle height is 42".

**Standard Lengths:** 7', 8' and 10'. Other sizes by special order.  
Bolts can be cut to size at job site.

**Hub Rotation:** Knob - 180° rotation. Lever - 90° rotation.

**Throw:** Knob Operation – 1.00" Lever Operation – 0.75"

**Spindle:** Cremones are supplied with a special spindle for double sided operation

**Bolts:**  
Bottom bolt: 0.625" wide x 40.01"  
Top bolt: 0.625" wide x 40.03" for a 7.0' Door  
Top bolt: 0.625" wide x 52.92" for a 8.0' Door  
Top bolt: 0.625" wide x 76.92" for a 10.0' Door

**Strikes:** Cremone Bolts are supplied with Mortise and Universal strikes. Angle strikes and Box strikes are available at an additional cost.

